



## 3G Mobile Router RUT104

User Manual



## LEGAL NOTICE

Copyright © 2012 TELTONIKA Ltd. All rights reserved. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of TELTONIKA Ltd is prohibited. The manufacturer reserves the right to modify the product and manual for the purpose of technical improvement without prior notice.

**Other product and company names mentioned herein may be trademarks or trade names of their respective owners.**

## CE COMPLIANCE

This equipment has been tested and found to comply with the limits for a Class B digital device. CE mark declaration of conformity can be found at Teltonika WEB page [www.teltonika.eu](http://www.teltonika.eu)

## ATTENTION



Before using the device we strongly recommend read this user manual.



Do not rip the device. Do not touch the device if the device block is broken or its connecting wires are without isolation.



All wireless devices for data transferring may be susceptible to interference, which could affect performance.



The device is not water-resistant. Keep it dry.



The device requires high 230V AC voltage.

### IMPORTANT NOTES!

**It is mandatory to read the notes and manual carefully before starting to use the device.**

## TECHNICAL SUPPORT CONTACTS

If you face any problems related to the device, which you are not able to solve by yourself, you are always welcome to address our technical support department by e-mail [support@teltonika.lt](mailto:support@teltonika.lt). We will be very glad to help you.

# Table of Contents

1	SAFETY INFORMATION .....	5
2	PRODUCT OVERVIEW .....	6
2.1	Introduction .....	6
2.2	Package contents .....	6
2.3	System requirements .....	6
2.4	RUT104 Hardware, LED's and connections .....	7
2.4.1	Back panel.....	7
2.4.2	Front panel .....	7
3	GETTING STARTED.....	8
3.1	Initial setup.....	8
3.2	Router installation guide.....	8
4	ROUTER CONFIGURATION .....	9
4.1	Connect to router WEB configuration page using wired connection.....	9
4.2	Connect to router WEB configuration page using wireless connection.....	10
4.3	WEB configuration page interface structure.....	11
4.4	Quick Setup.....	12
4.5	Status .....	13
4.5.1	System Information.....	13
4.5.2	Hardware information .....	14
4.5.3	Routes.....	14
4.5.4	Kernel log .....	14
4.6	Configuration.....	15
4.6.1	Mobile Network Settings.....	15
4.6.2	Network Settings .....	16
4.6.3	Wireless Settings .....	17
4.6.3.1	Hardware wireless settings.....	17
4.6.3.2	Software wireless settings.....	17
4.6.4	Dynamic DNS Settings.....	18
4.6.5	Services.....	19
4.6.5.1	SSH.....	19
4.6.5.2	HTTP .....	19
4.7	VPN .....	20
4.7.1	OpenVPN (site to site) .....	20
4.7.1.1	Server configuration.....	21
4.7.1.2	Client configuration .....	22
4.7.2	GRE Tunnel.....	23
4.7.3	IPsec .....	24
4.7.3.1	Manual IPSec Key exchange .....	24
4.7.3.2	Automatic IPSec Key exchange .....	25
4.8	Admin .....	26
4.8.1	Account.....	26
4.8.2	NTP.....	26
4.8.3	Firmware upgrade.....	27
4.8.4	Troubleshoot file .....	27
4.9	Firewall.....	28
4.9.1	Traffic rules .....	28
4.9.2	Traffic rules additional settings.....	29
4.9.3	Port forwarding.....	30
4.9.4	DMZ.....	31
4.10	Tools .....	31
4.10.1	Site Survey .....	31
4.10.2	Ping Reboot.....	32

4.10.3	Diagnostics .....	32
4.11	Reboot and Logout.....	32
5	TECHNICAL SPECIFICATION.....	33
6	Appendix A Configuring PC wireless security.....	35
7	Appendix B Changing router IP address.....	37
8	Appendix D Accessing RUT from the WEB .....	38
9	Appendix E SIM card public or private IP address .....	39

## 1 SAFETY INFORMATION

In this document you will be introduced how to use 3G Mobile Router safely. We suggest you to adhere to following recommendations to avoid any damage to person or property.


You have to be familiar with the safety requirements before starting to use the device! 3G Mobile Router is used to provide a mobile Internet access using a GSM network. To avoid burning and voltage caused traumas, of the personnel working with device, please follow these safety requirements.




Device requires power supply source that satisfies all safety requirements listed in LST EN 60950-1 standard. Each power supply source should not exceed 15VA.



The PC and power supply source, to which the device is connected, should satisfy LST EN 60950-1 standard. The device can be used on first (Personal Computer) or second (Notebook) computer safety class.




Disconnect device from power supply before mounting to avoid voltage effect!



Do not mount or serve device during a thunderbolt.

To avoid mechanical damages of the device it is recommended to transport the device packed in damage-proof pack. While using the device, it should be placed so, that its indication LED would be visible as they inform in which working mode the device is and if it has any working problems.

Protection against over currents, short circuits and earth faults should be provided as a part of the building installation. Two pole protective device is required to protect from short-circuit and earth fault. The power of connected device should satisfy power of release device. To disconnect the device plug off AC/DC power adapter from the wall outlet or power strip. The interstice between contacts should be no less than 3mm.



Signal level of the device depends on the environment in which it is working. If the device starts working insufficiently only qualified personnel may repair this product. We recommend to forward it to repair centre or to manufacturers. No exchangeable parts inside of the device.

## 2 PRODUCT OVERVIEW

### 2.1 Introduction

Teltonika 3G Mobile Router provides WAN connectivity to wired and wireless clients using the 3G cellular data network. It allows multiple users to get IEEE 802.11 compliant connection within your wireless broadband network with a single 3G data access account and SIM card. 3G Mobile Router is extremely useful for mobile work teams or emergency crews that need access to the broadband Internet but have no permanent base. The 3G/IEEE 802.11 router might be an easy solution to provide Internet connection for commuter vehicles, such as trains or company buses. Quickly set up a IEEE 802.11 hotspot Internet connection to check email and browse the web or share files.

### 2.2 Package contents

RUT104
<ul style="list-style-type: none"><li>• 3G HSPA+ Mobile Router</li><li>• External Wireless LAN antenna</li><li>• External GSM antenna</li><li>• Power adapter</li><li>• DIN Rail (<b>optional</b>)</li><li>• Leaflet “Quick Start Guide”</li></ul>

**Note:** The manufacturer does not supply the SIM card, which is mandatory for setting up a connection to the GSM network! The SIM card may be purchased from your GSM (mobile) service provider!

**Note:** Using a power supply with a different voltage rating than the one included with the RUT104 will cause damage and void the warranty for this product.

**Note:** If any of the components is missing or damaged, please contact the retailer or reseller from which this product was purchased.

### 2.3 System requirements

A computer with Windows®, Macintosh® or Linux-based operating systems with a network connection (wired or wireless).

A web browser Internet Explorer 6.0, Netscape Navigator™ 6.0, Opera 9.0, Mozilla 5.0 or later versions for configuration.



## 2.4 RUT104 Hardware, LED's and connections


### 2.4.1 Back panel



**Figure 1** Router back panel view.

1. Main GSM antenna connection.
2. Wireless LAN antenna connection.
3. Aux GSM antenna connection.
4. Wireless LAN antenna connection.

### 2.4.2 Front panel



**Figure 2** Router front panel view.

1. GSM LED.  
A solid light indicates proper connection of the 3G.
2. Reset button.
3. Ethernet socket.
4. Ethernet LED. A solid light indicates proper connection of the Ethernet. A blinking light indicates data transfer.
5. Power LED. A solid light indicates a proper connection to the power supply.
6. SIM card socket.
7. Power supply adapter socket.

## 3 GETTING STARTED

### 3.1 Initial setup

3G Mobile Router enables to access network using a wireless connection from virtually anywhere within the operating range of wireless network. Some things should be considered before finding place to set up access point:

1. Make sure the power outlet is nearby as the router requires power supply.
2. Keep the access point as central in work area as possible.
3. The number of walls and ceilings between the router and other network devices should be kept to a minimum as each wall or ceiling probably will reduce adapter's range from 1-30 meters. Signal strength and speed fall off with distance.
4. Higher is often better. Set up the router on the top shelf of a bookcase rather than the bottom one, if it is possible. The antenna usually works best if oriented to point straight up.
5. Building materials make a difference. A solid metal door or aluminum studs may have a negative effect on range. Try to position access point and computers so that the signal passes through drywall or open doorways. Materials and objects such as glass, steel, metal, walls with insulation, mirrors, file cabinets, bricks, and concrete will degrade wireless signal.
6. Keep router away (at least 1-2 meters) from electrical devices or appliances that generate RF noise.
7. If you are using 2.4GHz cordless phones or other wireless products your wireless connection may degrade dramatically or drop completely. Make sure your 2.4GHz phone base is as far away from your wireless devices as possible. The base transmits a signal even if the phone is not in use.

### 3.2 Router installation guide

1. Attach Wireless LAN and GSM antennas.
  - Remove the antenna from its plastic wrapper.
  - Screw the antenna in a clockwise direction to the back panel of the unit.
  - Position the antenna upward at its connecting joint. This will ensure optimal reception.
2. Insert the SIM card which was given by your GSM (mobile) service provider.
3. Insert the Ethernet cable into LAN Port if the router will be configured using wired connection.
4. Connect the power adapter to the socket on the front panel of 3G Mobile Router. Then plug the other end of the power adapter into a wall outlet or power strip.

**Note:** SIM card is mandatory for setting up connection to the GSM network. However, the manufacturer of this equipment does not supply the SIM card. The SIM card can be purchased from your GSM (mobile) service provider! For APN, user name and password please contact your GSM (mobile) service provider. The 3G Mobile Router must be powered off while inserting or taking out the SIM card.




## 4 ROUTER CONFIGURATION

### 4.1 Connect to router WEB configuration page using wired connection

**Step 1** Connect 3G Mobile Router to your PC using LAN cable.


**Step 2** Setup Local Area Network adapter on your computer (Go to **Start > Control Panel > Network and Internet > Network and Sharing Center**. In the left pane click **Change adapter settings** link. Right click on **Local Network Connection** and select **Properties**)





**Step 3** Setup the Local Area network adapter's IP address. Choose **Internet Protocol Version 4 (TCP/IP)** and click **Properties**.

Setup the Local area network adapter to  
**Obtain an IP address automatically** and  
**Obtain DNS server address automatically**

Note: It is possible to assign manually static IP address within 192.168.0.2 - 192.168.0.254 address range with mask 255.255.255.0, gateway 192.168.0.1 and DNS server 192.168.0.1.



**Step 4** Open the Web browser and type the IP address of the router (Default: 192.168.0.1) and enter the 3G Mobile Router administrator login details to access the Web management tool:



The default administrator login settings are:

Login: **admin**

Password: **admin01**

**Note:** It is strongly recommended to change the password after the first router configuration.

**Step 5** After successful administrator log on you will see the main page of the 3G Mobile Router Web configuration interface. The device now is ready for configuration.

## 4.2 Connect to router WEB configuration page using wireless connection

**Note:** the Wireless network function is shipped disabled by default and the configuration for the first time can be made only by using wired connection.

**Step 1** Enable the wireless network connection . (Go to **Start > Control Panel > Network and Internet > Network and Sharing Center**. In the left pane click **Change adapter settings** link. Right click on **Wireless Network Connection** and select **Enable**.

**Step 2** Setup wireless network adapter on your computer (Right click on **Wireless Network Connection** and select **Properties**).

**Step 3** Setup the wireless network adapter's IP address (choose **Internet Protocol Version 4 (TCP/IP)** and click **Properties**):


Setup the wireless network adapter to  
**Obtain an IP address automatically** and  
**Obtain DNS server address automatically**

Note: It is possible to assign manually static IP address within 192.168.0.2 - 192.168.0.254 address range with mask 255.255.255.0, gateway 192.168.0.1 and DNS server 192.168.0.1.

**Step 4** Right click on **Wireless Network Connection** to see available wireless networks.

**Step 5** Choose the wireless network (default: Teltonika\_RUT104) from the list of available wireless networks.





**Step 6** Open the Web browser and type the device IP address (default 192.168.0.1) and enter the 3G Mobile Router administrator login details to access the Web management.



The default administrator login settings are:

Login: **admin**  
Password: **admin01**

**Step 6** After successful administrator log on you will see the main page of the 3G Mobile Router Web configuration interface. The device now is ready for configuration.



### 4.3 WEB configuration page interface structure

The main Web management menu is displayed after successful login into the system (**Figure 3**). From this menu all essential configuration pages are accessed.



**Figure 3** Main Management Menu

By default the **Quick Setup** menu is activated. The web management menu has the following structure:

**Quick Setup** – quick router configuration wizard.

#### **Status**

**System Information** – displays general information of the device status.

**Hardware information** – displays device hardware information.

**Routes** – displays the rules which are currently active on this system.

**Kernel log** – displays the information about device kernel activity.

#### **Configuration**

**Mobile Network Settings**

**Network Settings**

**Wireless Settings**

**Dynamic DNS Settings**

**Services** – SSH, HTTPS services management.

#### **VPN**

**OpenVPN** – Create site to site tunnel or site to multi site tunnels.

**GRE Tunnel** – Create GRE tunnel.

**IPsec** – IPsec client settings.

#### **Admin**

**Account** – change administrator's password.

**NTP** – Time and time synchronization settings.

**Firmware upgrade** – Upgrade device firmware and receive the Troubleshoot file.

#### **Firewall**

**Traffic Rules** – Defines policies traveling between different zones.

**Port Forwarding** – Create rules to forward the incoming data.

#### **Tools**

**Site Survey** – shows information about wireless networks in the local geography.


**Ping Reboot** – set up continuous ping IP address with possibility to automatically reboot router if no echo received.

**Diagnostics** – Network utilities such as “Ping”, “Traceroute” and “Nslookup” to diagnose the network connection.

## 4.4 Quick Setup

Use **Quick Setup** to quickly configure basic 3G Mobile Router settings. The configuration is made in four steps (this is the default page when accessing the administration web management interface).

To start quick setup wizard click button **QUICK SETUP**.



**Step 1.** Change router network settings if needed, if not, then leave as it is.

Network Settings	
<b>Router settings</b>	
Router IP address	192.168.0.1
Router subnet	255.255.255.0

**Step 2.** Configure mobile network settings. The configuration data should be provided by your ISP (Internet Service Provider).

3G Modem configuration	
<b>3G modem settings</b>	
APN	
PIN	
Authentication method	None


**Step 3.** Configure wireless network settings.

Wireless Settings	
<b>Hardware settings</b>	
Enable Radio	<input checked="" type="checkbox"/>
IEEE mode	B/G Mixed
Channel	Auto
Transmit power(dBm)	100%
<b>Software settings</b>	
SSID	Teltonika_RUT104
Encryption	WPA-PSK
Cipher	auto
Key	*****

It is recommended to use **WPA-PSK** with **TKIP** or **AES** data encryption. The passphrase for data encryption may be 8-63 characters long and can include symbols (!?\*&\_) and spaces. This passphrase must be the same as Network key in the PC wireless network security settings. If encryption is chosen do not forget to configure your PC settings (refer to Appendix A).

Note: If **No Encryption** will be chosen it will let anyone within the range and with proper equipment to connect to your network.

**Step 4.** After successful configuration please click



button and then click the

**REBOOT**

button.

The router will reboot and start up with new settings. The process will take several minutes.

## 4.5 Status

### 4.5.1 System Information

System Information menu displays general devices status.

System Information	
Connection Information	
Signal Strength	40%
IMEI	357564013207802
PIN Status	READY
Network Status	REGISTERED (HOME NETWORK)
Operator	BITE
IP Address	10.13.25.206
DNS 1	213.226.131.131
DNS 2	193.219.88.36
Send Bytes	358833
Received Bytes	27576
Local Network Information	
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
DHCP Server	Enabled
Wireless Information	
IEEE Mode	B/G Mixed
Channel	auto
ESSID	Teltonika_RUT104

**Figure 4** *System Information*

**Connection information** – displays the GSM network information

**Local Network Information** – displays local network configuration.

**Wireless Information** – displays wireless network information.

## 4.5.2 Hardware information

Hardware Information	
<b>System</b>	
Uptime	1h 23m 55s
Firmware version	RUT104_T_00.00.16
Average system load	1min: 0.00, 5min: 0.01, 15min: 0.05
LAN MAC address	00:1E:42:00:20:40
WLAN MAC address	00-80-48-51-CB-62
<b>Memory</b>	
Total Available	18108 kB / 29952 kB (60%)
Free	8768 kB / 29952 kB (29%)
Cached	6888 kB / 29952 kB (22%)
Buffered	2452 kB / 29952 kB (8%)

Figure 5 Hardware information

**Uptime** – displays the time since the system was last rebooted.

**Firmware version** – displays current version of the firmware.

**Average system load** – displays the average load of the device processor in the period of the last 1 minute, 5 minutes and 15 minutes (a larger value means a larger average load on the processor: <1.0 – System is idle; =1.0 – Normal load; >1.0 – Processor is busy).

**LAN MAC address** – displays wired LAN MAC address.

**WLAN MAC address** – displays wireless LAN MAC address.

**Memory** – displays total, free, cached and buffered system memory.

## 4.5.3 Routes

Routes

The following rules are currently active on this system.

ARP

IPv4-Address	MAC-Address	Interface
192.168.0.200	00:e0:4c:00:ef:90	br-lan

Active IPv4-Routes

Network	Target	IPv4-Gateway	Metric
lan	192.168.0.0/24	0.0.0.0	0

Figure 6 Routes information

**ARP** – ARP Table shows map of the IP addresses assigned to the MAC addresses.

**Active IPv4-Routes** – shows the active LAN and WAN routes.

## 4.5.4 Kernel log

The Kernel log displays the information about device kernel activity.

Kernel Log
<pre>ered new interface driver usbfs [ 0.290000] usbcore: registered new interface driver hub [ 0.290000] usbcore: registered new device driver usb [ 0.310000] NET: Registered protocol family 2 [ 0.310000] IP route cache hash table entries: 1024 (order: 0, 4096 bytes) [ 0.310000] TCP established hash table entries: 1024 (order: 1, 8192 bytes) [ 0.310000] TCP bind hash table entries: 1024 (order: 0, 4096 bytes) [ 0.310000] TCP: Hash tables configured (established 1024 bind 1024) [ 0.310000] TCP reno registered [ 0.310000] UDP hash table entries: 256 (order: 0, 4096 bytes) [ 0.310000] UDP-Lite hash table entries: 256 (order: 0, 4096 bytes) [ 0.320000] NET: Registered protocol family 1 [ 0.320000] PCI: CLS 16 bytes, default 16 [ 0.330000] squashfs: version 4.0 (2009/01/31) Phillip Lougher [ 0.330000] JFFS2 version 2.2 (NAND) (SUMMARY) (LZMA) (RTIME) (CMODE_PRIORITY) (c) 2001-2006 Red Hat, Inc.</pre>

Figure 7 Kernel log information



## 4.6 Configuration


### 4.6.1 Mobile Network Settings

To set up the GSM connection SIM card is required. SIM card is not supplied with the router. It may be purchased from internet service provider.

The following information to connect to the internet is required:

1. **APN.** Access Point Name (APN).
2. **PIN.** SIM card PIN number.
3. **Authentication method.** The authentication protocol, which is used by your Internet Service Provider [None, CHAP or PAP].
4. **User Name.** If GSM operator does not require username, leave it blank.
5. **Password.** If GSM operator does not require password, leave it blank.
6. **Enable manual DNS.** If GSM operator does not require manual DNS, leave it disabled.
7. **DNS server 1.** If GSM operator does not require DNS server 1, leave it blank.
8. **DNS server 2.** If GSM operator does not require DNS server 2, leave it blank.

**Warning:** It is strongly recommended to use SIM card with PIN disabled. Otherwise, if the entered PIN will be wrong, the SIM card will be locked.



The screenshot shows a web interface titled "Modem Settings". Under the "Connection parameters" section, there are several input fields and a dropdown menu:

Connection parameters	
APN	<input type="text"/>
PIN	<input type="text"/>
Authentication method	<input type="text" value="PAP/CHAP"/>
User Name	<input type="text"/>
Password	<input type="password"/>
Enable manual DNS	<input checked="" type="checkbox"/>
DNS server 1	<input type="text"/>
DNS server 2	<input type="text"/>

**Figure 8** Mobile network configuration.

**APN** – Access Point Name (APN)

**PIN** – SIM card pin number.

**Authentication method** – Select authentication type PAP, CHAP or None.

**User Name** – Enter your User Name for your mobile connection.

**Password** – Enter your Password for your mobile connection.

**Enable Manual DNS** – check to enter custom DNS server IP addresses

**DNS server 1** and **DNS server 2** are ISP domain servers.

### 4.6.2 Network Settings

This section will allow you to change the local network settings of the router and to configure the DHCP settings

The figure shows a web interface for 'Network Settings'. It has two main sections: 'Router settings' and 'DHCP settings'. Under 'Router settings', there are two input fields: 'Router IP address' with the value '192.168.0.1' and 'Router subnet' with the value '255.255.255.0'. Under 'DHCP settings', there is a checkbox labeled 'Enable DHCP' which is checked.

Network Settings	
<b>Router settings</b>	
Router IP address	192.168.0.1
Router subnet	255.255.255.0
<b>DHCP settings</b>	
Enable DHCP	<input checked="" type="checkbox"/>

Figure 9 Network settings.

**Router IP address.** The IP address of the router. The default IP address is 192.168.0.1.

**Subnet mask.** The Subnet Mask of the router. The default subnet mask is 255.255.255.0.

**Enable DHCP server.** Check the box to enable the DHCP server on your router. Uncheck to disable this function

Enabled DHCP server allows configuring IP addresses pool that will be assigned by the router.

The figure shows the same 'Network Settings' web interface as Figure 9, but with more fields visible under the 'DHCP settings' section. The 'Enable DHCP' checkbox is checked. Below it are fields for 'IP address from' (192.168.0.2), 'IP address to' (192.168.0.254), 'Lease time' (12), 'Lease time scale' (Hours), 'WINS address', and 'Domain'.

Network Settings	
<b>Router settings</b>	
Router IP address	192.168.0.1
Router subnet	255.255.255.0
<b>DHCP settings</b>	
Enable DHCP	<input checked="" type="checkbox"/>
IP address from	192.168.0.2
IP address to	192.168.0.254
Lease time	12
Lease time scale	Hours
WINS address	
Domain	

Figure 10 Network settings.

**IP address from.** Starting IP addresses for the DHCP server's IP assignment.

**IP address to.** Ending IP addresses for the DHCP server's IP assignment.

**Lease time.** Determines how long IP addresses are assigned for you. During the lease time, the DHCP server cannot assign that IP address to any other clients. The purpose of a lease is to limit the length of time that a client may use an IP address. A lease prevents unused clients from taking up IP addresses when there are more clients than addresses. Enter the Lease time in seconds.

**WINS address.** If WINS (Windows Internet Naming Service ) server is specified, the router at system startup, will register its name and IP address with the WINS server. WINS server is used for mapping host names to network addresses. This results in fast and efficient host name resolution. Specify WINS server IP address.

**Domain.** Enter the domain name for the Router. Some ISP's require it for identification. Check your ISP to see if your broadband Internet service has been configured with a domain name. In most cases, leaving these fields blank will work.

### 4.6.3 Wireless Settings

#### 4.6.3.1 Hardware wireless settings



The screenshot shows the 'Hardware settings' section of a router's configuration interface. It contains four rows of settings:

Hardware settings	
Enable Radio	<input checked="" type="checkbox"/>
IEEE mode	B/G Mixed
Channel	auto
Transmit power(dBm)	100%

Figure 11 Wireless network settings.


**Enable radio.** Check the box to enable the wireless function. If you do not want to use wireless network, uncheck the box to disable the wireless function.

**IEEE mode.** Specify the wireless network mode [B, G, mixed B/G, G Dynamic Turbo].

**Channel.** Select the channel for the wireless network.

**Transmit power.** Set the maximum transmitter radiation power.

#### 4.6.3.2 Software wireless settings



The screenshot shows the 'Software settings' section of a router's configuration interface. It contains twelve rows of settings:

Software settings	
SSID	Teltonika_RUT104
Fragmentation	
RTS	
Fast Frames	<input type="checkbox"/>
Packet Bursting	<input type="checkbox"/>
Compression	<input type="checkbox"/>
Quality of service(WMM)	<input type="checkbox"/>
User isolation	<input type="checkbox"/>
Hide ESSID	<input type="checkbox"/>
Encryption	WPA-PSK
Cipher	auto
Key	.....

Figure 12 Wireless network settings.

**SSID.** Specify a unique name for your wireless network.

**Fragmentation.** Specify the fragmentation threshold (in bytes), which determines whether data frames will be fragmented and at what size [256-2346/off/auto]. On the 802.11 wireless LAN, frames exceeding the fragmentation threshold will be fragmented, i.e., split into smaller units suitable for the circuit size. Data frames smaller than the specified fragmentation threshold value are not fragmented. Default: off.

**RTS.** Specify the maximum packet size beyond which the wireless LAN card invokes it's RTS/CTS mechanism [0-2347/off/auto]. Packets that exceed the specified RTS threshold trigger the RTS/CTS mechanism. The card transmits packets smaller than this threshold without using RTS/CTS. Default: off.

**Fast Frames.** Packet aggregation and timing modifications. Default: off.

**Packet Bursting.** More data frames per given time period. Default: off.

**Compression.** Standards based (Lempel Ziv) real-time hardware compression. Default: off.

**Quality of service (WMM).** Check the box to enable applications such as audio, video and voice to have higher priority than less-sensitive data applications.

**User isolation.** Check the box to isolate the wireless clients from communicating with each other.

**Hide ESSID.** Hides the wireless LAN SSID. Default: off.

**Encryption.** Choose the authentication method for wireless network:

**No Encryption.** It will let anyone within range and with the proper equipment to connect onto your network within the router operating range.

**WEP Open System** – choose the 64 bit WEP security with one of four pre-shared keys.

**WEP Shared Key**– choose the 128 bit WEP security with one of four pre-shared keys.

**WPA-PSK** – choose the WPA security with pre-shared key.

**WPA2-PSK** – choose the WPA2 security with pre-shared key.

**WPA-PSK/WPA2-PSK Mixed mode** – choose for the coexistence of WPA and WPA2 clients in.

**WPA-EAP** – choose to enable the certificate based authentication.

**WPA2-EAP** – choose to enable the certificate based authentication.

**Cipher.** Choose the encryption method:

**Auto** – Encryption method is chosen by device.

**Force CCMP (AES)** – Encryption by the AES algorithm.

**Force TKIP** – Encryption by the TKIP (Temporal Key Integrity Protocol) algorithm.

**Key.** Specify security key (passphrase) to protect your network.

**Note:** Setting a lower fragmentation threshold value can help improve connection reliability in noisy environments (where radio interference is present). This mechanism does add overhead and therefore reduces effective throughput.

**Note:** Setting a lower RTS threshold value can improve connection reliability and throughput in crowded wireless LAN environments (where many clients are trying to communicate simultaneously). It adds a certain amount of overhead, but can compensate for this by reducing bandwidth lost due to collisions.

#### 4.6.4 Dynamic DNS Settings

Dynamic DNS (DDNS) is a domain name service allowing to link dynamic IP addresses to static hostname. To start using this feature firstly you should register to DDNS service provider.



Dynamic DNS Settings	
Enable Dynamic DNS	<input type="checkbox"/>
User Name	<input type="text"/>
Password	<input type="password"/> 
Host name	<input type="text"/>
Update Period(seconds)	<input type="text"/>
DynDNS service type	<input type="text"/>

**Figure 13** *Dynamic DNS Settings.*

**Enable Dynamic DNS** – check the box to enable DDNS.

**User name** - enter your user name. The router will use it to automatically login to update your IP address in the DDNS server.

**Password** – enter you login password.

**Hostname** - enter your hostname which was registered in DDSN server.

**Update period** – enter IP address update time in seconds.

**DynDNS service type** – DYNDNS service type. Allowed are all DynDNS service types

#### 4.6.5 Services

In this section HTTP, SSH services which are important for remote control monitoring and management may be enabled and disabled.

##### 4.6.5.1 SSH

The image shows a web interface for SSH configuration. It has a title bar 'SSH configuration' and a sub-section 'SSH settings'. There are four rows of settings: 'Enable SSH' with a checked checkbox, 'Port' with a text box containing '22', 'Allow SSH from IP only' with an empty text box and a note 'empty means any IP address', and 'Enable access from WAN' with an unchecked checkbox.

SSH configuration	
SSH settings	
Enable SSH	<input checked="" type="checkbox"/>
Port	<input type="text" value="22"/>
Allow SSH from IP only	<input type="text"/> empty means any IP address
Enable access from WAN	<input type="checkbox"/>

Figure 14 SSH service configuration


**Enable SSH.** Check the box to enable SSH service.

**Port.** Set port value of the SSH service.

**Allow SSH from IP only.** Set the IP address which should be allowed to use SSH connection.

**Enable access form WAN.** Check the box to enable access via SSH from WAN.

##### 4.6.5.2 HTTP

The image shows a web interface for HTTP(s) settings. It has a title bar 'HTTP(s) settings' and a sub-section 'Remote access'. There are six rows of settings: 'Enable HTTP access from WAN' (checked), 'HTTP port override' (80), 'Allow HTTP from IP only' (empty text box with note), 'Enable HTTPS access from WAN' (checked), 'HTTPS port override' (443), and 'Allow HTTPS from IP only' (empty text box with note).

HTTP(s) settings	
Remote access	
Enable HTTP access from WAN	<input checked="" type="checkbox"/>
HTTP port override	<input type="text" value="80"/>
Allow HTTP from IP only	<input type="text"/> empty means any IP address
Enable HTTPS access from WAN	<input checked="" type="checkbox"/>
HTTPS port override	<input type="text" value="443"/>
Allow HTTPS from IP only	<input type="text"/> empty means any IP address

Figure 15 HTTP service configuration

**Enable HTTP access from WAN.** Check the box to enable management though HTTP from WAN.

**HTTP port override.** Set port number for the HTTP management from WAN.

**Allow HTTP from IP only.** Set the IP address which should be allowed to use HTTP connection.

**Enable HTTPS access from WAN.** Check the box to enable management though HTTPS from WAN.


**HTTPS port override.** Set port number for the HTTPS management from WAN.

**Allow HTTPS from IP only.** Set the IP address which should be allowed to use HTTP connection.

## 4.7 VPN

### 4.7.1 OpenVPN (site to site )

OpenVPN site to site graphical user interface (GUI) implementation allows connecting two remote networks via point-to-point encrypted tunnel. OpenVPN implementation offers a cost-effective simply configurable alternative to other VPN technologies. The OpenVPN security model is based on SSL, the industry standard for secure communications via the internet. OpenVPN implementation uses OSI layer 2 secure network extension using the SSL/TLS protocol. The typical VPN site to site implementation using OpenVPN is presented in **Figure 16**.



**Figure 16** Typical site to site OpenVPN tunnel configuration

Server configuration		Client configuration	
		Remote Endpoint IP	xxx.xxx.xxx.xxx
Local tunnel IP	10.0.0.1	Local tunnel IP	10.0.0.2
Remote tunnel IP	10.0.0.2	Remote tunnel IP	10.0.0.1
Remote network IP	192.168.1.0	Remote network IP	192.168.0.0
Remote network subnet mask	255.255.255.0	Remote network subnet mask	255.255.255.0

The OpenVPN implementation requires server to have public IP or hostname. Also the remote network subnets must be different as in Fig. 23 192.168.0.0/24 and 192.168.1.0/24. If the subnet will be the same tunnel will not be created or may not function correctly due to routing rules.

The server and client have almost the same configuration. The difference in the client configuration is the remote endpoint IP or hostname field. Also the client can set up the keep alive settings. For successful tunnel creation a static key must be generated on one side and the same key must be uploaded on the opposite side.

**OpenVPN**

**OpenVPN instances**  
Below is a list of configured OpenVPN instances and their current state

Tunnel Name	Tun/Tap	Protocol	Port	Status	
client_new	-	-	-	Disabled	<a href="#">Edit</a> <a href="#">Delete</a>

Role: Client  New configuration name:  [Add New](#)

**Figure 17** OpenVPN instances

**Role** – Select “Client” or “Server” role for the device.

**New configuration name** – Set the name for OpenVPN configuration.

**Edit** – Press Edit button to edit the OpenVPN configuration.

**Delete** – Press Delete button to delete the OpenVPN configuration.



#### 4.7.1.1 Server configuration

OpenVPN instance: 'server\_new'

**Main settings**

Enable	<input type="checkbox"/>
Tun/Tap	Tun(tunnel) <small>Type of used device</small>
Protocol	Udp
Port	<input type="text"/> <small>TCP/UDP port for both, local and remote</small>
LZO	<input type="checkbox"/> <small>Use fast LZO compression</small>
Debug level	5
Authentication	Static key
Local tunnel endpoint IP	<input type="text"/>
Remote tunnel endpoint IP	<input type="text"/>
Resolve Retry	infinite
Remote network IP address	<input type="text"/>
Remote network netmask	<input type="text"/>
Static pre-shared key	<input type="button" value="Choose File"/> No file chosen

Figure 18 Server configuration

**Enable.** Check box to enable the OpenVPN.

**Tun/Tap.** Select tunneled or bridged connection.

**Protocol.** Select UDP or TCP protocol.

**Port.** Set the OpenVPN port. Default port 1194.

**LZO.** Check box to enable the LZO compression. Default: disabled.

**Debug level.** Select the connection debugging level. Default: 5.

**Local tunnel endpoint IP.** Specify the IP address of the local VPN tunnel endpoint.

**Remote tunnel endpoint IP.** Specify the IP address of remote VPN tunnel endpoint.

**Resolve Retry.** Connection retry count. Default: infinite.

**Remote network IP address.** Specify the remote network IP address.

**Remote network netmask.** Specify the remote network subnet mask.

**Static pre-shared key.** Static key configurations offer the simplest setup, and are ideal for point-to-point VPNs. The GUI allows to upload the static key.

**Important!** The same key must be uploaded in server and client, e.g. if the key was generated in server, then it must be download by clicking Download , then uploaded in the remote client VPN configuration.

#### 4.7.1.2 Client configuration

OpenVPN instance: 'client\_new'

**Main settings**

Enable	<input checked="" type="checkbox"/>
Tun/Tap	Tun(tunnel) <small>Type of used device</small>
Protocol	Udp
Port	1194 <small>TCP/UDP port for both, local and remote</small>
LZO	<input type="checkbox"/> <small>Use fast LZO compression</small>
Debug level	5
Authentication	Static key
Remote host IP address	
Resolve Retry	infinite
Local tunnel endpoint IP	
Remote tunnel endpoint IP	
Remote network IP address	
Remote network IP netmask	
Static pre-shared key	<input type="button" value="Choose File"/> No file chosen

Figure 19 Client configuration

**Enable.** Check box to enable the OpenVPN.

**Tun/Tap.** Select tunneled or bridged connection.

**Protocol.** Select UDP or TCP protocol.

**Port.** Set the OpenVPN port. Default port 1194.

**LZO.** Check box to enable the LZO compression. Default: disabled.

**Debug level.** Select the connection debugging level. Default: 5.

**Authentication.** Choose the authentication type “Static key” or “Tls”.

**Remote host IP address.** Specify the remote device (OpenVPN server) IP address.

**Resolve Retry.** Connection retry count. Default: infinite.

**Local tunnel endpoint IP.** Specify the IP address of the local VPN tunnel endpoint.

**Remote tunnel endpoint IP.** Specify the IP address of remote VPN tunnel endpoint.

**Remote network IP address.** Specify the remote network IP address.

**Remote network netmask.** Specify the remote network subnet mask.

**Static pre-shared key.** Static key configurations offer the simplest setup, and are ideal for point-to-point VPNs. The GUI allows to upload the static key.

**Important!** The same key must be uploaded in server and client, e.g. if the key was generated in server, then it must be download by clicking Download , then uploaded in the remote client VPN configuration.

## 4.7.2 GRE Tunnel

GRE (Generic Routing Encapsulation RFC2784) is a solution for tunneling RFC1812 private address-space traffic over an intermediate TCP/IP network such as the Internet. GRE tunneling does not use encryption it simply encapsulates data and sends it over the WAN.




Figure 20 Typical GRE tunnel application connecting two remote networks

In the example network diagram (Fig. 22) two distant networks LAN1 and LAN2 are connected. To create GRE tunnel the user must know the following parameters:

1. Source and destination IP addresses (From Fig. 22 A.A.A.A and B.B.B.B).
2. Tunnel local IP address
3. Distant network IP address and Subnet mask

GRE Tunnel	
GRE is a solution for tunneling RFC1812 private address-space traffic over an intermediate TCP/IP network	
<b>Local network settings</b>	
Enable GRE tunnel	<input checked="" type="checkbox"/>
TTL	<input type="text"/> Value [0-255]
PMTUD	<input type="checkbox"/>
Remote tunnel endpoint IP address	<input type="text"/>
Remote network IP address	<input type="text"/>
Remote CIDR	<input type="text"/> Cidr value [0-32]
MTU	<input type="text"/> MTU value [0-1500]

Figure 21 GRE tunnel settings

**Enable GRE Tunnel.** Check the box to enable the GRE Tunnel function.

**TTL.** Specify the fixed time-to-live (TTL) value on tunneled packets [0-255]. The 0 is a special value meaning that packets inherit the TTL value.

**Enable PMTUD.** Check the box to enable the Path Maximum Transmission Unit Discovery (PMTUD) status on this tunnel.

**Remote tunnel endpoint IP address.** Set remote tunnel Endpoint IP address.

**Remote network IP address.** Specify remote LAN IP address.

**Remote CIDR.** Specify remote LAN Subnet CIDR value.

**MTU.** Specify the maximum transmission unit (MTU) of a communications protocol of a layer in bytes.

### 4.7.3 IPsec

The IPsec protocol client enables the router to establish a secure connection to an IPsec peer via the Internet. IPsec is supported in two modes - transport and tunnel. Transport mode creates secure point to point channel between two hosts. Tunnel mode can be used to build a secure connection between two remote LANs serving as a VPN solution.

IPsec system maintains two databases: Security Policy Database (SPD) which defines whether to apply IPsec to a packet or not and specify which/how IPsec-SA is applied and Security Association Database (SAD), which contain Key of each IPsec-SA.

The establishment of the Security Association (IPsec-SA) between two peers is needed for IPsec communication. It can be done by using manual or automated configuration.

Note: router starts establishing tunnel when data from router to remote site over tunnel is sent. For automatic tunnel establishment used tunnel keep alive feature.

#### 4.7.3.1 Manual IPsec Key exchange

The screenshot displays the 'IPsec' configuration page with the following sections and settings:

- Basic ipsec configuration**
  - Description**
    - Enable IPsec: ☒
    - IPSec key exchange mode: Manual Key (dropdown)
    - Enable NAT traversal: ☐
    - Enable initial contact: ☐
    - Peers identifier type: fqdn (dropdown)
- Phase 1**
  - Encryption: 3des (dropdown)
  - Hash: sha1 (dropdown)
  - Dh group: modp1024 (dropdown)
- Phase 2**
  - PFS group: modp1024 (dropdown)
  - Encryption: 3des (dropdown)
  - Authentication: hmac\_sha1 (dropdown)
- Remote network secure group**
  - IP address: (text input)
  - Subnet mask: (text input) with a hint '(Number [0-32])'
- Tunnel keep alive**
  - Ping IP address: (text input)
  - Ping period (seconds): (text input)

Figure 22 Manual IPsec Key exchange

**Enable IPsec.** Check box to enable IPsec

**IPsec key exchange mode.** Select the Manual or Automatic Key exchange.

**Enable NAT traversal.** Enable this function if client-to-client applications will be used.

**Peers identifier type.** Choose “fqdn” or “user fqdn” accordingly to your IPsec server configuration.

**Phase 1 and Phase 2** must be configured accordingly to the IPsec server configuration.

**Remote Network Secure Group** – Set the remote network (Secure Policy Database) information.

**Tunnel keep alive.** Allows sending ICMP echo request (ping utility) to the remote tunnel network. This function may be used to automatically start the IPsec tunnel.

### 4.7.3.2 Automatic IPsec Key exchange

The screenshot displays the 'IPsec' configuration window, titled 'Basic ipsec configuration'. It is organized into several sections:

- Description:** Contains settings for 'Enable IPsec' (checked), 'IPSec key exchange mode' (set to 'Auto Key (IKE)'), 'Enable NAT traversal' (unchecked), 'Enable initial contact' (unchecked), 'Peers identifier type' (set to 'fqdn'), 'Mode' (set to 'main'), 'My identifier' (empty), 'Preshare Key' (empty, with a note '(Length [6-32])'), and 'Remote VPN endpoint' (empty, with a note 'IP address').
- Phase 1:** Contains 'Encryption' (set to '3des'), 'Hash' (set to 'sha1'), and 'Dh group' (set to 'modp1024').
- Phase 2:** Contains 'PFS group' (set to 'modp1024'), 'Encryption' (set to '3des'), and 'Authentication' (set to 'hmac\_sha1').
- Remote network secure group:** Contains 'IP address' (empty) and 'Subnet mask' (empty, with a note '(Number [0-32])').
- Tunnel keep alive:** Contains 'Ping IP address' (empty) and 'Ping period (seconds)' (empty).

Figure 23 Authentication header settings

**Enable IPsec.** Check box to enable IPsec

**IPsec key exchange mode.** Select the Manual or Automatic Key exchange.

**Enable NAT traversal.** Enable this function if client-to-client applications will be used.

**Peers identifier type.** Choose “fqdn” or “user fqdn” accordingly to your IPsec server configuration.

**Mode.** Select “Main” or “Aggressive” mode accordingly to your IPsec server configuration.

**My identifier.** Set the device identifier for IPsec tunnel.

**Preshare key** – specify the authentication secret [string]. Secret’s length depends on selected algorithm, eg. 128 bit long secret is 16 characters in length, 128 bits / 8 bits (one character) = 16.

**Remote VPN Endpoint** – set remote IPsec server IP address.

**Phase 1 and Phase 2** must be configured accordingly to the IPsec server configuration.

**Remote Network Secure Group** – Set the remote network (Secure Policy Database) information.

**Tunnel keep alive.** Allows sending ICMP echo request (ping utility) to the remote tunnel network. This function may be used to automatically start the IPsec tunnel.

**Ping IP address** – Enter IP address to which ICMP echo requests will be sent.

**Ping period (seconds)** – Set sent ICMP request period in seconds.

## 4.8 Admin

Use the **Admin** menu to define access settings to the device, or to use the following system utilities:

- **Account** – change administrator’s password.
- **NTP** – Manage system time and date.
- **Firmware upgrade** – new firmware upgrade.

### 4.8.1 Account

The Administrative Account menu is used for changing the existing administrators’ password.




Figure 24 Change administrator password

**Enter password** – enter the new administrator password.

**Verify password** – re-enter the new password to verify its accuracy.

**Note:** The only way to gain access to the web management if you forget the administrator password is to reset the device factory default settings. Default administrator login settings are:

User Name: **admin**

Password: **admin01**

### 4.8.2 NTP

Use this section to manage the system time and date on the device automatically, using the Network Time.




Figure 25 Time setting using NTP

**Current system time.** Show the current device time.

**Update interval.** Time update interval in seconds.



**Timezone.** Choose from UTC or GMT time.

**Time Servers.** Set your own or use predefined time synchronizations servers.

**Delete** – click to remove selected NTP servers from the device system.

**Add** – click **Add** button to add time server. The new field with server will appear.

### 4.8.3 Firmware upgrade

To update your device firmware use the **Firmware upgrade** section, select the firmware file and click the Firmware upgrade button:




Figure 26 *Firmware update*

**Choose File** – Click the button to select new firmware image from a folder on the PC.

**Firmware upgrade** – Upload the new firmware.

### 4.8.4 Troubleshoot file

Troubleshoot file contains all device debug log files and they are used to detect, analyze and solve various problems which device could experience during operation.




Figure 27 *Firmware update*

To receive and save the troubleshoot file on your PC press the “Download troubleshoot file” button.

## 4.9 Firewall

This section allows configuring firewall for enhanced router security.

### 4.9.1 Traffic rules

#### Firewall - Traffic Rules

Traffic rules define policies for packets traveling between different zones, for example to reject traffic between certain hosts or to open WAN ports on the router.

##### Traffic Rules

Enable	Name	Family	Protocol	Source	Destination	Action		
<input checked="" type="checkbox"/>	Allow-DHCP-Renew	IPv4	UDP	From <i>any host in wan</i>	To <i>any router IP</i> at port <i>68</i> on <i>this device</i>	Accept input	Edit	Delete
<input checked="" type="checkbox"/>	Allow-Ping	IPv4	ICMP with type <i>echo-request</i>	From <i>any host in wan</i>	To <i>any router IP</i> on <i>this device</i>	Accept input	Edit	Delete
<input checked="" type="checkbox"/>	New Rule	Any	TCP, UDP	From <i>any host in wan</i>	To <i>any router IP</i> at port <i>7081</i> on <i>this device</i>	Accept input	Edit	Delete

**Open ports on router:**

Name	Protocol	External port	
<input type="text"/>	TCP+UDP	<input type="text"/>	<input type="button" value="Add"/>

☒ Save

Figure 28 Traffic rules

This page displays the currently created active or disabled rules with short description of every rule. Here new rules can be added; the existing rules can be edited or deleted.

**Enable.** Check or uncheck the box to enable or disable the rules.

**Name.** Displays the name of rules.

**Protocol.** Displays the protocol to which the rule is bind.

**Source.** Shows the source address and its area.

**Destination.** Shows the rule destination and assigned port.

**Action.** Displays the rule current action.

**Edit.** Press to edit the rule.

**Delete.** Press the remove the rule.

To add a new rule:

Write a name for new rule in **Name** field.

Choose the required protocol in **Protocol** field.

Set the required port number in **External port** field.

Press **Add** button.

For more detailed configuration of a newly or already existing rule press the **Edit** button near the required rule.

## 4.9.2 Traffic rules additional settings

Here you can edit the settings of newly created or existing rule.

Firewall - Traffic Rules - New Rule

This page allows you to change advanced properties of the traffic rule entry, such as matched source and destination hosts.

Enable rule	<input checked="" type="checkbox"/>
Name	<input type="text" value="New Rule"/>
Restrict to address family	<input type="text" value="IPv4 and IPv6"/>
Protocol	<input type="text" value="TCP+UDP"/>
Source zone	<input type="radio"/> Any zone <input type="radio"/> lan <input type="radio"/> vpn <input checked="" type="radio"/> wan
Source MAC address	<input type="text"/>
Source address	<input type="text"/>
Source port	<input type="text"/>
Destination zone	<input checked="" type="radio"/> Device (input) <input type="radio"/> Any zone (forward) <input type="radio"/> lan <input type="radio"/> vpn <input type="radio"/> wan
Destination address	<input type="text"/>
Destination port	<input type="text" value="7081"/>
Action	<input type="text" value="accept"/>

[Back to Overview](#) [Save](#)

Figure 29 Additional settings

**Enable rule.** Check the box to enable the rule.

**Name.** Set the rule name.

**Restrict to address family.** Set the required address family. IPv4, IPv6 (isn't supported yet) or both.

**Protocol.** Choose the required protocol or set the custom one.

**Source zone.** Select the require zone for rule or assign rule to all zones.

**Source MAC address.** Set MAC address of the source zone device which will use this rule.

**Source address.** Set the IP address of the source zone device which will use this rule.

**Source port.** Set the port which the source device will use for data transfer.

**Destination zone.** Select the required zone for rule; assign it to all zones or to a router.

**Destination address.** Set the IP address of the destination device to which the data will pass from source address.

**Destination port.** Set the port to which the router will pass the data incoming from source zone port.

**Action.** Set the action for a rule. Drop, accept, reject or don't track the incoming/outgoing connection in selected zone.

**Protocol Type.** Select TCP, UDP, ICMP or ALL.

**Save.** Save made changes

**Back to Overview.** Return to the traffic rules main page.

### 4.9.3 Port forwarding

This section will let to manage port forwarding.

**Ports forwarding**

**Port forwarding rules**

Application Name	Input port range	Protocol	Destination IP address	Destination port range
		UDP		
		UDP		
		UDP		
		UDP		
		UDP		
		UDP		
		UDP		
		UDP		
		UDP		
		UDP		
		UDP		

**Figure 30** Port forwarding settings

**Application name.** Set the name of the application.

**Input port range.** Set incoming port value or range.

**Protocol.** Select TCP, UDP, or BOTH

**Destination IP address** Enter the IP address of the computer on your local network that you want to allow the incoming service to be forwarded.

**Destination port range.** Set destination port value or range

**Example 1:** Forward TCP port 40000 to IP address 192.168.0.100

**Example 2:** Forward UDP port 40000 to IP address 192.168.0.100 port 50000.

**Example 3:** Forward TCP and UDP ports range 4000-7000 to IP address 192.168.0.100 port 5000.

**Ports forwarding**

**Port forwarding rules**

Application Name	Input port range	Protocol	Destination IP address	Destination port range
Example 1	4000	TCP	192.168.0.100	
Example 2	4000	UDP	192.168.0.100	5000
Example 3	4000:7000	Both	192.168.0.100	5000
		UDP		
		UDP		
		UDP		
		UDP		
		UDP		
		UDP		
		UDP		
		UDP		

**Figure 31** Port Forwarding examples

#### 4.9.4 DMZ

A DMZ host is not protected by the firewall and may be vulnerable to attack. You should only use this feature when a special application's function fails to make an application work. Designating a DMZ host may also put other computers in the local network at risk. When designating a DMZ host, you must consider the security implications and protect it if necessary.



The image shows a web interface for DMZ settings. It has a title bar 'DMZ zone'. Below it, there is a section with two items: 'Enable' with a checkbox, and 'Destination IP address' with a text input field.

Figure 32 DMZ settings

**Enable** - Click to enable or disable the DMZ.

**Destination IP address** - Type a host IP address for the DMZ. All remaining incoming packets will be sent to this IP address.


### 4.10 Tools

#### 4.10.1 Site Survey

The Site Survey test shows overview information for wireless networks in a local geographic area. Using this test, an administrator can scan for working access points, check their operating channels, encryption and see signal/noise levels. An administrator can use this feature to identify a clear channel to set the device.

**Note:** Note that Site Survey function can take several minutes to perform.

A Site Survey test is performed every time on the startup of the device, therefore the results of the last performed Site Survey test and its time can be found on the page. Thus, to obtain the results, the initiation of the scan is not necessary. To perform the Site Survey test currently, click the **Scan** button:



The image shows a web interface for site survey. It has a title bar 'Site survey'. Below it, there is a section titled 'Networks' containing a table with columns: Link, ESSID, BSSID, Channel, Protocol, Mode, Encr., Power, and Scan. There is one row of data and a 'Scan' button.


Link	ESSID	BSSID	Channel	Protocol	Mode	Encr.	Power	Scan
0/70	Teltonika_RUT100	00:80:48:51:CB:62	auto		ap	psk	20 dBm	 Scan

Figure 33 Site Survey Table

**Note:** The Site Survey function is impossible if the selected wireless interface is disabled.

### 4.10.2 Ping Reboot

The Ping Reboot feature allows rebooting the router if the connection to GSM network is lost. This feature checks (using ICMP echo request, like ping utility) if specific hosts are accessible on the network. Function allows adding several host IP addresses. When at least one server does not respond the router is rebooted if the check box “Enable reboot if no echo received”.

Figure 34 Site Survey Table

**Enable** – check the box to enable Ping Reboot feature.

**Ping interval** – specify the monitoring time period in seconds

**Time scale** – set ping interval time scale in minutes or hours

**Retry count** – specify the number of failed reach ability checks

**Enable reboot if no echo received**– enable reboot the router if no echo to sent ICMP requests is received.

**Server to ping** – Set the host IP address to which ICMP requests will be sent.

### 4.10.3 Diagnostics

Network utilities such as “Ping”, “Traceroute” and “Nslookup” to diagnose the network connection.

Figure 35 Diagnostic tools

### 4.11 Reboot and Logout

Use the **Reboot** button to reboot the device or press **Logout** button to log off from device configuration menu:



## 5 TECHNICAL SPECIFICATION

### Wireless IEEE 802.11 network

#### Standards

IEEE 802.11b: 11Mbps, 5.5Mbps, 2Mbps, 1Mbps

IEEE 802.11g: 54Mbps, 48Mbps, 36Mbps, 24Mbps, 18Mbps, 12Mbps, 9Mbps, 6Mbps, automatically fall back to 5.5Mbps, 2Mbps, 1Mbps

#### Transmitter output power at antenna connector

IEEE 802.11b:	1-11Mbps	20dBm
IEEE 802.11g:	6-24Mbps	20dBm
	36Mbps	19dBm
	48Mbps	17dBm
	54Mbps	16dBm

#### Receiver sensitivity at antenna connector

IEEE 802.11b: -92 dBm @ 1Mbps

-87 dBm @ 11Mbps

IEEE 802.11g: -90 dBm @ 6Mbps

-70 dBm @ 54Mbps

#### Security

WPA/WPA2, WEP 64/128 bit

#### Wireless Frequency Range

2.412GHz to 2.484GHz

#### External Antenna Type

Detachable reverse SMA

### Management

User-friendly Web GUI

Wired and wireless network status.

Site survey test.

Traffic monitoring.

Firmware upgradeable.

SSH

### VPN

IPsec pass through, GRE Tunnel pass through

GRE tunnel, IPsec client

## **RUT104 Quad Band (850/900/1900/2100 MHz) GSM/EDGE/GPRS/HSUPA/HSDPA/UMTS**

### **RUT104 Power Class:**

Power Class 4 (2 W, 33 dBm) for GSM/GPRS 850/900 MHz bands

Power Class 1 (1 W, 30 dBm) for GSM/GPRS 1800/1900 MHz bands

Power Class E2 (0.5 W, 27 dBm) for EDGE 850/900 MHz bands

Power Class E2 (0.4 W, 26 dBm) for EDGE 1800/1900 MHz bands

Power Class 3 (0.25 W, 24 dBm) for UMTS 850/900/1900/2100 MHz bands

Power Class 3 (0.25 W, 24 dBm) for 1xRTT & EVDO

### **Electrical characteristics**

Nominal power supply voltage	9V	12V	21V
Current Consumption when idle	--- 600mA	--- 350mA	--- 300mA
Current Consumption when operating	--- 980mA	--- 520mA	--- 400mA

### **Temperature & Humidity**

Operation 0° to 55° C

Humidity 5% to 95% (non-condensing)

Transit/Storage -40° to 85° C

### **LEDS**

Power

Mobile Network Activity

LAN Activity

### **Host Operating System**

Microsoft Windows® 98SE/ME/NT4.0/2000/XP/Vista/7/8, Unix, Linux and MacOS

### **RUT104 Dimensions**

L = 100mm

W = 85mm


H = 36mm

### **RUT104 Weight**


230g

## 6 Appendix A Configuring PC wireless security

1. Enable the wireless network connection . (Go to **Start > Control Panel > Network and Internet > Network and Sharing Center**. In the left pane click **Change adapter settings** link. Right click on **Wireless Network Connection** and select **Enable**.




2. Setup wireless network adapter on your computer (Right click on **Wireless Network Connection** select, choose **Internet Protocol Version 4 (TCP/IP)** and click **Properties**)
3. Select **Obtain IP address automatically** and **Obtain DNS server address automatically** if they are not selected. Click **OK**.




4. Right click on **Wireless Network Connection** to see available wireless networks.




5. Select **Wireless** from **Show** drop down list to see only wireless networks. Choose the network with SSID which was configured on the router (default **Teltonika\_RUT104**) and click **Connect**.

If you don't see your network, click  to refresh the list.



6. The window asking for the **Security key** should appear. The **Security key** is the **key (passphrase)** which was typed in the router settings



## 7 Appendix B Changing router IP address

**Step 1** Connect to router WEB configuration page. Then go **CONFIGURATION** then **Maintenance**.

**Step 2** Change router IP address:

In the field **Router IP address** write new router address. (eg. 192.168.123.1)

The screenshot shows the 'Network Settings' page. Under 'Router settings', the 'Router IP address' field is highlighted with a red dashed box and contains the value '192.168.0.1'. The 'Router subnet' field contains '255.255.255.0'. Below this, the 'DHCP Settings' section is visible, with 'Enable DHCP' checked. The 'IP address from' field is '192.168.0.2' and the 'IP address to' field is '192.168.0.254'. Other fields include 'Lease time' (12), 'Lease time scale' (Hours), 'WINS address', and 'Domain'.

Network Settings	
<b>Router settings</b>	
Router IP address	192.168.0.1
Router subnet	255.255.255.0
<b>DHCP Settings</b>	
<b>DHCP settings</b>	
Enable DHCP	<input checked="" type="checkbox"/>
IP address from	192.168.0.2
IP address to	192.168.0.254
Lease time	12
Lease time scale	Hours
WINS address	
Domain	

**Step 2** Change router DHCP server assigned IP address range:

Type the fields **IP address from** and **IP address to** type new range

Example:

**Router IP address:** 192.168.123.1

**IP address from:** 192.168.123.2

**IP address to:** 192.168.123.254

This screenshot is similar to the previous one, but the 'IP address from' and 'IP address to' fields in the DHCP settings are highlighted with a red dashed box. The 'IP address from' field contains '192.168.0.2' and the 'IP address to' field contains '192.168.0.254'. The 'Router IP address' field still contains '192.168.0.1'.

Network Settings	
<b>Router settings</b>	
Router IP address	192.168.0.1
Router subnet	255.255.255.0
<b>DHCP Settings</b>	
<b>DHCP settings</b>	
Enable DHCP	<input checked="" type="checkbox"/>
IP address from	192.168.0.2
IP address to	192.168.0.254
Lease time	12
Lease time scale	Hours
WINS address	
Domain	

**Step 3** Reboot the router.

## 8 Appendix D Accessing RUT from the WEB

There are two ways to connect the router from internet:

1. Using SIM card with public static IP address
2. Using SIM card with public dynamic IP address which will be linked to static hostname using DDNS service.

**Note:** If the SIM card is with private IP address then reaching camera from the internet is not possible as connection is routed through a NAT firewall in your provider's network.

### SIM card with public static IP address


Open your WEB browser and type SIM card IP address, when the camera GSM connection has been set up. After successful connection router's login page must appear.

### SIM card with public dynamic IP address

For the SIM card with dynamic public IP address the IP address is given for a limited period of time, which is usually no more than a few hours, then the IP address is changed. As the IP address is continuously changed it becomes a problem to connect to the camera. To solve this problem Dynamic Domain Name Service (DDNS) may be used. DDNS is a domain name service allowing to link dynamic IP addresses to static hostname.

To start using this feature firstly a hostname must be registered on the DDNS server. After creating account you will get: Hostname Username and Password.

To link router's IP address to the static hostname, Dynamic DNS settings must be configured. To configure DDNS connect to the router WEB configuration page, go the **Configuration => Dynamic DNS Settings** (Refer to Figure below).



The screenshot shows the 'Dynamic DNS Settings' page. It contains a table with the following fields:

Dynamic DNS Settings	
Enable Dynamic DNS	<input type="checkbox"/>
User Name	<input type="text"/>
Password	<input type="password"/> <a href="#">C</a>
Host name	<input type="text"/>
Update Period(seconds)	<input type="text"/>
DynDNS service type	<input type="text"/>

Check the **Enable** check box. Enter username, password and hostname which were got from the DDNS server provider. In the Update period field enter the IP address update interval. Enter the DDNS service provider. After setting DDNS settings press **Save** button, then press reboot to start router with new settings.

## 9 Appendix E SIM card public or private IP address

**Step 1** Connect PC to router and check if it is possible to browse Internet.

If you are not able then there is problem with MOBILE NETWORK SETTINGS. If you are able then go to next step.

**Step 2** Type [www.whatismyip.com](http://www.whatismyip.com) in the web browser and write down the red marked IP address.



**Step 3** Connect to router web configuration tool and then go STATUS – System Information and write down the marked IP address.

Connection Information	
Signal Strength	40%
IMEI	357564013207802
PIN Status	READY
Network Status	REGISTERED (HOME NETWORK)
Operator	BITE
IP Address	10.13.25.206
DNS 1	213.226.131.131
DNS 2	193.219.88.36
Send Bytes	358833
Received Bytes	27576

**Step 4** Compare the IP addresses in step 2 and 3. If they are the same then SIM card is with public IP address, if they are different SIM card is with private IP address.